

## MR008L Toxicological Assessment Using Compound Specific Analyzer-Combustion Products (CSA-CP)

### 3.2 Medical Requirements Overview

**TABLE 3.2: MEDICAL REQUIREMENTS OVERVIEW**

<b>MRID# and Title:</b>	MR008L Toxicological Assessment Using Compound Specific Analyzer-Combustion Products (CSA-CP)
<b>Sponsor:</b>	Medical Operations
<b>Discipline:</b>	Environmental Health
<b>Category:</b>	Medical Requirements
<b>References:</b>	ISS Medical Operations Requirements Document SSP 50260
<b>Purpose/Objectives:</b>	To provide monitoring of the ISS environment if a pyrolysis event is suspected or during decontamination of the atmosphere once an event has taken place. It is also present to guide donning and doffing of PPE. The Compound Specific Analyzer-Combustion Products (CSA-CP) monitor provides real-time readings following a combustion event and subsequent clean-up efforts. This information may be used to guide donning and doffing of PPE.
<b>Measurement Parameters:</b>	Detection and concentration of carbon monoxide, hydrogen chloride, hydrogen cyanide and oxygen.
<b>Deliverables:</b>	Real-time assessment of crew exposure to specific noxious combustion by-products.
<b>Flight Duration:</b>	≥30 days
<b>Number of Flights:</b>	Every ISS Expedition
<b>Number and Type of Crewmembers Required:</b>	1 crewmember to act as operator
<b>Other Flight Characteristics:</b>	N/A

# MR008L Toxicological Assessment Using Compound Specific Analyzer-Combustion Products (CSA-CP)

## 3.3 Preflight Training

**TABLE 3.3: PREFLIGHT TRAINING**

Preflight Training Activity	Description:	Training/Familiarization will be covered under the following Environmental Health System (EHS) documents and lessons: EHS Toxicological Operations			
		Duration:	Schedule:	Flexibility:	Personnel Required:
	Schedule:	EHS Toxicological Operations: Experienced CM      30 min Inexperienced CM    85 min	L-18 months	N/A	Crewmembers/Instructors
Ground Support Requirements Hardware/Software	Preflight Hardware:		Preflight Software:	Test Location:	
	CSA-CP CSA Cal Adapter Portable Gas Delivery System CSA-CP Sampling Pump CSA-CP Zero Filter CSA-CP Sampling Pump Filters CSA-CP Data Cable CSA-CP Sample Probe CSA-CP/CDM Battery Packs Station Support Computer (SSC)		CSA-CP Software on SSC	U.S	
Training Facilities	Minimum Room Dimensions:	Number of Electrical Outlets:	Temperature Requirements:	Special Lighting:	
	29' x 14'	1 (One)	Ambient	N/A	
	Hot or Cold Running Water:	Privacy Requirements:	Other:		
	N/A	N/A	1 Table & 6-8 chairs		
Constraints/Special Requirements:	None				
Launch Delay Requirements:	Refresher training will be available upon crewmember request.				
Notes:	Experienced crewmembers (CM) – those CMs who have had previous EHS Toxicology Operations Training. Inexperienced CMs – those CMs who have never had EHS Toxicology Operations Training.EHS Toxicology Operations includes training for GSC, FMK, CSA-CP, Portable Oxygen Monitor, CDMK, Portable Gas Delivery System, and Air Quality Monitor (AQM).				

## MR008L Toxicological Assessment Using Compound Specific Analyzer-Combustion Products (CSA-CP)

### 3.4 Preflight Activities

**TABLE 3.4: PREFLIGHT ACTIVITIES –Launch Delay Requirements**

<b>Preflight Activity</b>	No Preflight Activity
<b>Launch Delay Requirements:</b>	For launch delay of $\geq 30$ days (scrub turnaround), the hardware owners and/or Toxicology may choose to refurbish and/or recalibrate the CSA-CPs
<b>Notes:</b>	None
<b>Data Delivery</b>	N/A

### 3.5 Inflight Activities

**TABLE 3.5.1: In-Flight Activities**

**Table 3.5.1a CSA-CP Nominal Ops**

In-Flight Activity	Description:	CSA-CP Nominal Ops: During nominal operations the four CSA-CP monitors remain powered down; two deployed in Node 1 and two deployed in the Russian Service Module (SM). All crewmembers will know exactly where the units are located in case a pyrolysis event (i.e., fire) is suspect or confirmed.		
	Schedule:	Duration	Schedule	Personnel Required
		5 min - unstow 5 min – activate 5 min restow (if necessary)	If a pyrolysis event is suspect or confirmed:	1 Crewmember Unattended during unpowered deployment
Procedures:		Procedures can be found in the Systems Operations Data File (SODF) Med Ops book: CSA-CP Operations for CSA-CP monitoring		
Constraints / Special Requirements:		CSA-CP deployed locations should be readily accessible in case a pyrolysis event is suspected or confirmed		
Photo/TV Requirements:		None.		
Cold Stowage Requirements:		N/A		
Mission Extension Requirements:		The CSA-CP monitors must be resupplied based on the calibration interval of the sensors.		
Notes:		Location of CSA-CP monitors: Two deployed in Node 1 and two deployed in the Russian Service Module (SM).		
Data Delivery		CSA-CP data may be verbally communicated to MCC or recorded and downloaded from the CSA-CP and downlinked to ground. Air quality issues will be worked immediately by the Toxicology Section. If warranted, contingency reporting will be included in the overall air quality assessment report provided by the Toxicology Section.		

## MR008L Toxicological Assessment Using Compound Specific Analyzer-Combustion Products (CSA-CP)

**Table 3.5.1: In-Flight Activities (cont'd)**

**Table 3.5.1b CSA-CP Activation & Checkout**

In-Flight Activity	Description:	CSA-CP Activation & Checkout: <ul style="list-style-type: none"><li>Deploy 4 newly resupplied CSA-CP monitors after the battery packs are replaced, the date/time/data logger on each monitor has been reset with the laptop, and the CP sensors have been zero calibrated.</li><li>Periodic sensor readings are taken to monitor biased sensor levels until they have reached nominal levels.</li></ul>		
	Schedule:	Duration	Schedule	Personnel Required
		70 min. (total) Part I: 50 min Part II: 20 min	Once every resupply (approximately every 9 months). Data measurements 6-8 days following resupply may be needed to monitor off-gassing and sensor settling of new units.	1 CM
Procedures:		Procedures can be found in the Systems Operations Data File (SODF) Med Ops book: CSA-CP Activation and Checkout.		
Constraints / Special Requirements:		None		
Photo/TV Requirements:		None		
Cold Stowage Requirements:		N/A		
Notes:		The 4 CSA-CP monitors being replaced onboard the ISS will be returned to the JSC Toxicologist for postflight evaluation.		
Data Delivery		Data from ACO, can be reported to MCC-H, or .xml data can be retrieved from the procedure.		

**Table 3.5.1c CSA-CP Sampling Pump Battery Changeout - As Needed**

In-Flight Activity	Description:	CSA-CP Sampling Pump Battery Changeout: Replace the battery pack within the Sampling Pump		
	Schedule:	Duration	Schedule	Personnel Required
		20 min total crew time: 10 min. unstow/stow 10 min. changeout	As needed, when audible beep from pump sounds every 30 seconds.	1 CM
Procedures:	Procedures can be found in the Systems Operations Data File (SODF) Med Ops book: CSA-CP Sampling Pump Battery Changeout			
Constraints / Special Requirements:	Notify MCC-H when the battery changeout is completed.			
Photo/TV Requirements:	None			
Cold Stowage Requirements:	N/A			
Notes:	None			
Data Delivery	N/A			

# MR008L Toxicological Assessment Using Compound Specific Analyzer-Combustion Products (CSA-CP)

**Table 3.5.1: In-Flight Activities (cont'd)**

**Table 3.5.1d CSA-CP Sampling Pump Filter Changeout – As Needed**

In-Flight Activity	Description:	CSA-CP Sampling Pump Filter Changeout: Replace the filter on the Sampling Pump		
	Schedule:	Duration	Schedule	Personnel Required
		<u>15 min total crew time:</u> 10 min. unstow/stow 5 min. changeout	As needed, when pump goes into low flow alarm mode	1 CM
<b>Procedures:</b>	Procedures can be found in the Systems Operations Data File (SODF) Med Ops book: CSA-CP Sampling Pump Filter Changeout			
<b>Constraints / Special Requirements:</b>	None			
<b>Photo/TV Requirements:</b>	None			
<b>Cold Stowage Requirements:</b>	N/A			
<b>Notes:</b>	None			
<b>Data Delivery</b>	N/A			

**Table 3.5.1e CSA-CP Extended Routine Maintenance – Every 60 Days**

In-Flight Activity	Description:	CSA-CP Extended Routine Maintenance: Battery Change out, zero-calibrated and values are compared in all units.		
	Schedule:	Duration	Schedule	Personnel Required
		<u>45 min total crew time:</u> 10 min. unstow/stow, 35 min. battery change out, zero calibrated and compare 4 units.	Every 60 Days	1 CM
<b>Procedures:</b>	Procedures can be found in the Systems Operations Data File (SODF) Med Ops book: CSA-CP Extended Routine Maintenance			
<b>Constraints / Special Requirements:</b>	None			
<b>Photo/TV Requirements:</b>	None			
<b>Cold Stowage Requirements:</b>	N/A			
<b>Notes:</b>	None			
<b>Data Delivery</b>	Data from Extended Routine Maintenance can be reported to MCC-H, or .xml data can be retrieved from the procedure.			

## MR008L Toxicological Assessment Using Compound Specific Analyzer-Combustion Products (CSA-CP)

**Table 3.5.1: In-Flight Activities (cont'd)**

**Table 3.5.1f CSA-CP Data Download – Contingency**

<b>In-Flight Activity</b>	<b>Description:</b>	CSA-CP Data download: Data stored in the datalogger is downloaded to the SSC		
	<b>Schedule:</b>	<b>Duration</b>	<b>Schedule</b>	<b>Personnel Required</b>
		30 min	Contingency Only	1 Operator
<b>Procedures:</b>	Procedures can be found in the Systems Operations Data File (SODF) Med Ops book: CSA-CP Data Download			
<b>Constraints / Special Requirements:</b>	None			
<b>Photo/TV Requirements:</b>	None			
<b>Cold Stowage Requirements:</b>	N/A			
<b>Notes:</b>	None			
<b>Data Delivery</b>	CSA-CP data will be downlinked from the SSC to the Ground for analysis.			

**Table 3.5.1g CSA-CP Data Logger Activation/Deactivation - Contingency**

<b>In-Flight Activity</b>	<b>Description:</b>	CSA-CP Data Logger Activation/Deactivation: Turns the data logger on or off.		
	<b>Schedule:</b>	<b>Duration</b>	<b>Schedule</b>	<b>Personnel Required</b>
		5 min	Contingency Only	1 CM
<b>Procedures:</b>	Procedures can be found in the Systems Operations Data File (SODF) Med Ops book: CSA-CP Data Logger Activation/Deactivation			
<b>Constraints / Special Requirements:</b>	Notify MCC-H in the event of a contingency If contingency, CSA-CP download should occur immediately after this activity.			
<b>Photo/TV Requirements:</b>	None			
<b>Cold Stowage Requirements:</b>	N/A			
<b>Notes:</b>	Data are downloaded to MCC-H in contingency situations.			
<b>Data Delivery</b>	Evaluation of CSA-CP data following a contingency incident, e.g. fire, will be worked real-time by the Toxicology Section. A preliminary assessment will be provided as soon as possible, typically within an hour, after receipt of all pertinent information. CSA-CP data is saved on the Toxicology server which is backed-up daily.			

## MR008L Toxicological Assessment Using Compound Specific Analyzer-Combustion Products (CSA-CP)

**Table 3.5.1: In-Flight Activities (cont'd)**

**Table 3.5.1h Contingency Sampling using CSA-CP**

<b>In-Flight Activity</b>	<b>Description:</b>	Contingency Sampling using CSA-CP <ul style="list-style-type: none"> <li>Unit mated with sampling pump and probe</li> <li>Activate data logger</li> </ul>		
	<b>Schedule:</b>	<b>Duration</b>	<b>Schedule</b>	<b>Personnel Required</b>
		As Needed: 10 min unstow, assemble, activate 3 min/sample (as needed during sampling time duration) 10 min deactivate, disassemble, stow	Contingency only	1 CM
<b>Procedures:</b>	Procedures can be found in the Systems Operations Data File (SODF) Med Ops book: CSA-CP Active Sampling with Probe and Data Logging			
<b>Constraints / Special Requirements:</b>	Sampling may be required when difficulty in breathing, irritation of airways, headache, confusion and at discretion of crewmember or Flight Surgeon			
<b>Photo/TV Requirements:</b>	Photo documentation is required during contingency situations.			
<b>Cold Stowage Requirements:</b>	N/A			
<b>Mission Extension Requirements:</b>	None			
<b>Notes:</b>	Data are downloaded to MCC-H in contingency situations.			
<b>Data Delivery</b>	Evaluation of CSA-CP data following a contingency incident, e.g. fire, will be worked real-time by the Toxicology Section. A preliminary assessment will be provided as soon as possible, typically within an hour, after receipt of all pertinent information. CSA-CP data is saved on the Toxicology server which is backed-up daily.			

**Table 3.5.1i CSA-CP Alarm/Autolog Setpoint Change – Contingency**

<b>In-Flight Activity</b>	<b>Description:</b>	CSA-CP Alarm/Autolog Setpoint Change: Sets the instantaneous alarm thresholds (setpoints)		
	<b>Schedule:</b>	<b>Duration</b>	<b>Schedule</b>	<b>Personnel Required</b>
		20 min	Contingency Only	1 CM
<b>Procedures:</b>	Procedures can be found in the Systems Operations Data File (SODF) Med Ops book: CSA-CP Alarm/Autolog Setpoint Change			
<b>Constraints / Special Requirements:</b>	Notify MCC-H prior to changing any alarm/autolog setpoint.			
<b>Photo/TV Requirements:</b>	None			
<b>Cold Stowage Requirements:</b>	N/A			
<b>Notes:</b>	N/A			
<b>Data Delivery</b>	N/A			

## MR008L Toxicological Assessment Using Compound Specific Analyzer-Combustion Products (CSA-CP)

**Table 3.5.1: In-Flight Activities (cont'd)**

**Table 3.5.1j Post Fire Analysis using CSA-CP – Contingency**

<b>In-Flight Activity</b>	<b>Description:</b>	Post Fire Analysis using CSA-CP: <ul style="list-style-type: none"> <li>• Monitor air quality using at least two CSA-CP units</li> <li>• Download Data to SSC</li> </ul>		
	<b>Schedule:</b>	<b>Duration</b>	<b>Schedule</b>	<b>Personnel Required</b>
		As needed: 20 min. unstow, activate, and deploy units 3 min/sample (as needed sampling time duration) 5 min. deactivate and stow units 30 min. data download to SSC	Contingency only	1 CM
<b>Procedures:</b>	Procedures can be found in the Systems Operations Data File (SODF) Med Ops book: Post Fire Air Analysis			
<b>Constraints / Special Requirements:</b>	Sampling may be required when difficulty in breathing, irritation of airways, headache, confusion and at discretion of crewmember or Flight Surgeon. For CO > 50ppm an additional measurement is required using the CO Draeger Tube.			
<b>Photo/TV Requirements:</b>	Photo(s) showing deployment location(s) during contingency operations is (are) required.			
<b>Cold Stowage Requirements:</b>	N/A			
<b>Mission Extension Requirements:</b>	None			
<b>Notes:</b>	Data are downloaded to MCC-H in contingency situations.			
<b>Data Delivery</b>	Evaluation of CSA-CP data following a contingency incident, e.g. fire, will be worked real-time by the Toxicology Section. A preliminary assessment will be provided as soon as possible, typically within an hour, after receipt of all pertinent information. CSA-CP data is saved on the Toxicology server which is backed-up daily.			

**TABLE 3.5.1k CSA-CP BATTERY PACK CHANGEOUT - Contingency**

<b>In-flight Activity</b>	<b>Description:</b>	CSA-CP/CDM Battery Pack Changeout: The battery pack is replaced in the unit when required (aside from nominal maintenance)		
	<b>Schedule:</b>	<b>Duration:</b>	<b>Schedule:</b>	<b>Personnel Required:</b>
		10 min per CSA-CP monitor	As needed	1 CM
<b>Procedures:</b>	Procedures can be found in the Systems Operations Data file (SODF) Med Ops book: CSA-CP – Battery Changeout			
<b>Constraints/Special Requirements:</b>	Should only be performed if a CSA-CP unit is indicating Low Battery status.			
<b>Photo/TV Requirements</b>	None			
<b>Cold Storage Requirements</b>	N/A			
<b>Notes:</b>	None			
<b>Data Delivery</b>	N/A			



## MR008L Toxicological Assessment Using Compound Specific Analyzer-Combustion Products (CSA-CP)

**TABLE 3.5.2: IN-FLIGHT HARDWARE**

Hardware/Software Name
CSA-CP Monitor Assembly
CSA Cal Adapter
Portable Gas Delivery System
CSA-CP Sampling Pump
CSA-CP Sampling Pump Filters
CSA-CP Zero Filter
CSA-CP Sample Probe
CSA-CP/CDM Battery Packs
CSA-CP Data Cable
Station Support Computer (SSC)
CSA-CP Software

### 3.6 Postflight Activities – No Postflight Activities

# MR008L Toxicological Assessment Using Compound Specific Analyzer-Combustion Products (CSA-CP)

## 3.7 Summary Schedule

**TABLE 3.7: SUMMARY SCHEDULE**

ACTIVITY	DURATION	SCHEDULE	PERSONNEL REQUIRED	CONSTRAINTS
<b>Preflight Training</b>				
EHS Toxicology Operations:	30 min	L-12 months	Crewmembers/Instructors	None
Experienced CM	85 min			
Inexperienced CM				
<b>Preflight: N/A</b>				
<b>In-Flight</b>				
CSA-CP Nominal Ops	5 min - unstow 5 min – activate 5 min restow (if necessary)	If a pyrolysis event is suspect or confirmed	1 CM Unattended during nominal operations	The CSA-CP monitors are deployed (unpowered) as follows: • Two in Node 1 • Two in the Russian Service Module (SM)
CSA-CP Activation & Checkout	70 min. Total Part I: 50 min Part II: 20 min	Once every resupply (approximately every 9 months). Data measurements 6-8 days following resupply may be needed to monitor off-gassing of new units.	1 CM	
CSA-CP Sampling Pump Battery Changeout	20 min	As needed	1 CM	Notify MCC-H when the battery changeout is completed.
CSA-CP Sampling Pump Filter Changeout	15 min	As needed	1 CM	None
CSA-CP Extended Routine Maintenance	45 min	Every 60 Days	1 CM	None
CSA-CP Data Download - Contingency	30 min	Contingency only	1 CM	None
CSA-CP Data Logger Activation/Deactivation - Contingency	5 min	Contingency only	1 CM	Notify MCC-H in the event of a contingency If contingency, CSA-CP download should occur immediately after this activity

## MR008L Toxicological Assessment Using Compound Specific Analyzer-Combustion Products (CSA-CP)

Contingency Sampling using CSA-CP	10 min – Unstow, Assemble, Activate 3 min/sample 10 min – Deactivate, Disassemble, Stow	Contingency only	1 CM	Photo in contingency situation  Sampling may be required when there is difficulty in breathing, irritation of airways, headache, confusion and at discretion of crewmember or Flight Surgeon.
CSA-CP Alarm/Autolog setpoint Change - Contingency	20 min	Contingency only	1 CM	Notify MCC-H prior to changing any alarm/autolog setpoint
Post fire Analysis using CSA-CP - Contingency	25 min – Unstow/Stow 3 min/sample 30 min data download	Contingency only	1 CM	Photo in contingency situation  Sampling may be required when difficulty in breathing, irritation of airways, headache, confusion and at discretion of crewmember or Flight Surgeon.  For CO > 50 ppm, an additional measurement is required using the CO Draeger Tube.
<b>Postflight: N/A</b>				
<b>Postflight Debrief:</b>				
Crew Debrief	15 min.	~R+30 days	Crewmembers & Toxicology Team	Included as part of the overall Med Ops debrief.